



### TO OPEN LID CORRECTLY

1. Twist and Pull Locking Pin away from lid. Pin will stop before it comes fully out.
2. Lift lever on lid until it flips all the way forward.
3. Ensure arms are fully released from bars. Using lever, lift lid up to open.

### TO CLOSE LID CORRECTLY

1. Using lever, lift lid up and forward to rest seal in place.
2. Close cap by moving maximum forwards.
3. Push lever back and down all the way until arms have slid through side bars tightly.
4. Twist and Push Locking Pin into guide on lid until it comes out the other side.

## VIDEO INSTRUCTION

### ÖFFNEN

1. Lockern Sie den Stift durch Auf- und Abbewegen des Verschlusses.
2. Drehen Sie den Stift eine Viertel Umdrehung und ziehen Sie ihn heraus.
3. Öffnen Sie den Deckel durch Anheben des Verschlusses.

### SCHLIEßEN

1. Heben Sie den Verschluss an und setzen Sie den Deckel auf den Stützen.
2. Ziehen Sie dabei den Deckel so weit wie möglich nach vorne.
3. Drücken Sie den Verschluss nach unten.
4. Schieben Sie den Verschlussstift ein. Dabei wiederum den Verschluss leicht auf- und ab bewegen.